

B-36 left wing
misc dimensions

Rods is are used to align
motor nacelle formers

